



- 1 SEDM-L
- 2 Solid wall construction
- 3 Firepro firestop compound
- 4 Overplating strip (e.g. Supalux-S, th. 12mm, width 40 to 50mm)
- 5 Screw UNI 4x40mm (span 200 to 250mm)
- 6 Spacing strip (e.g. Supalux-S, th. 12mm, width 40 to 50mm)
- 7 M8 bolt assembly (bolt M8x105mm, 2 pcs large washer M8, nut M8)

Damper must be located with the damper blade central in wall thickness.



* recommended size

Dimensions also apply to the top and bottom

Drilling areas for routing the connection cable to the actuator

example drilled holes

45

30

45

30

The diagram illustrates the three-step process of installing a window blind:

- Step 1:** Mounting brackets to the wall. Two brackets are shown being attached to a brick wall using screws.
- Step 2:** Inserting the blind into the brackets. The blind is shown being placed into the brackets, with a pair of pliers used to assist in the process.
- Step 3:** Adjusting the blind. A screwdriver is used to adjust the blind, ensuring it is properly aligned and functioning.

Intellectual property of MANDIK Ltd. Unauthorised use shall be punishable by law